

# ENGLISH SUMMER ALE

Official NORTHERN BREWER Instructional Document

It's an ale. It's made for Summer consumption. It uses English-leaning hops. What's there to get? Inspired by the hoppy ales of Southeastern England, this is a beer that explodes with life, even at a young age. Floral waxy sweetness from the late honey addition mixes with the aromatic tendencies of Styrian Goldings (Celeia) and Crystal to bring a rich complexity of apricots, soft citrus, and resinous freshly-cut grass. Firmly bittered, the even hop presence plants this squarely in ESB-land, but the reduced maltiness, fluffy wheaty body, and dryness from the honey keep things light and sessionable. A hop-lover's beer in a different framing than the standard pale ale or IPA, the end result is a full suffusion of Corvallis-cum-Kent.

**O.G: 1.056 READY: 4 WEEKS**

1 week primary, 1 week secondary,  
2-3 weeks bottle conditioning

**BREWER'S NOTE:** Do a "hop stand", allowing the Crystal addition to steep for 20-80 minutes (depending upon patience) before chilling. Failing that, half the last Crystal addition, reserving half for 5-7 days of dry hopping.

## KIT INVENTORY:

### MAILLARD MALTS™ SPECIALTY GRAIN

- 0.75 lbs Baird's Carastan Light
- 0.25 lbs Belgian Biscuit Malt

### MAILLARD MALTS™ EXTRACTS & OTHER FERMENTABLES

- 6 lbs Gold malt syrup
- 1 lb Briess Wheat DME
- 1 lb Light-Amber Honey late addition (0 min)

### HOPTIMUS REX™ PREMIUM HOPS & OTHER FLAVORINGS

- 1 oz Palisade (60 min)
- 1 oz Styrian Goldings (Celeia) (20 min)
- 2 oz Crystal (0 min, see brewer's note above)

## YEAST

- **DRY YEAST (DEFAULT):** Danstar Windsor  
Optimum Temp: 64-70°F
- **LIQUID YEAST OPTION:** Wyeast 1968 London ESB Attenuation: 68-71%. Flocculation: High. Optimum temp: 64-72° F.

## PRIMING SUGAR

- 5 oz Priming Sugar (save for Bottling Day)

## BEFORE YOU BEGIN ...

### MINIMUM REQUIREMENTS

- Homebrewing starter kit for brewing 5 gallon batches
- Boiling kettle of at least 3.5 gallons capacity
- A 5 gallon carboy, with bung and airlock, to use as a secondary fermenter – If you do not have a secondary fermenter you may skip the secondary fermentation and add an additional week to primary fermentation before bottling
- Approximately two cases of either 12 oz or 22 oz pry-off style beer bottles

## UNPACK THE KIT

- Refrigerate the yeast upon arrival
- Locate the Kit Inventory (above) – this is the recipe for your beer, so keep it handy
- Doublecheck the box contents vs. the Kit Inventory
- Contact us immediately if you have any questions or concerns!

## PROCEDURE

### A FEW DAYS BEFORE BREWING DAY

1. Remove the liquid Wyeast pack from the refrigerator, and "smack" as shown on the back of the yeast package. Leave it in a warm place (70-80° F) to incubate until the pack begins to inflate. Allow at least 3 hours for inflation; some packs may take up to several days to show inflation. Do not brew with inactive yeast – we can replace the yeast, but not a batch that fails to ferment properly. If you are using dry yeast, no action is needed.

### ON BREWING DAY

2. Collect and heat 2.5 gallons of water.
3. For mail-order customers grains for extract kits come crushed by default, but if you requested uncrushed grains, crush them now. Pour crushed grain into supplied mesh bag and tie the open end in a knot. Steep for 20 minutes or until water reaches 170°F. Remove bag and discard.
4. Bring to a boil, remove the kettle from the burner and stir in the 6 lbs Gold malt syrup and 1 lb Wheat DME.
5. Return wort to boil. The mixture is now called "wort", the brewer's term for unfermented beer.
  - Add 1 oz Palisade hops, and boil for 60 minutes.
  - Add 1 oz Styrian Goldings hops 20 min before the end of the boil.
  - Add 1 lb Light-Amber Honey and 2 oz of Crystal at the end of the boil. Wait for 20 minutes before proceeding with the next step.
6. Cool the wort. When the 60-minute boil and hop stand is finished, cool the wort to approximately 100° F as rapidly as possible. Use a wort chiller, or put the kettle in an ice bath in your sink.
7. Sanitize fermenting equipment and yeast pack. While the wort cools, sanitize the fermenting equipment – fermenter, lid or stopper, fermentation lock, funnel, etc – along with the yeast pack and a pair of scissors.
8. Fill primary fermenter with 2 gallons of cold water, then pour in the cooled wort. Leave any thick sludge in the bottom of the kettle.
9. Add more cold water as needed to bring the volume to 5 gallons.
10. Aerate the wort. Seal the fermenter and rock back and forth to splash for a few minutes, or use an aeration system and diffusion stone.
11. Measure specific gravity of the wort with a hydrometer and record.
12. Add yeast once the temperature of the wort is 78°F or lower (not warm to the touch). Use the sanitized scissors to cut off a corner of the yeast pack, and carefully pour the yeast into the primary fermenter.

13. Seal the fermenter. Add approximately 1 tablespoon of water to the sanitized fermentation lock. Insert the lock into rubber stopper or lid, and seal the fermenter.

14. Move the fermenter to a warm, dark, quiet spot until fermentation begins.

### BEYOND BREWING DAY, WEEK 1

15. Active fermentation begins. Within approximately 48 hours of Brewing Day, active fermentation will begin – there will be a cap of foam on the surface of the beer, the specific gravity as measured with a hydrometer will drop steadily, and you may see bubbles come through the fermentation lock. The optimum fermentation temperature for this beer is 64-72° F – move the fermenter to a warmer or cooler spot as needed.

16. Active fermentation ends. Approximately one week after brewing day, active fermentation will end. When the cap of foam falls back into the new beer, bubbling in the fermentation lock slows down or stops, and the specific gravity as measured with a hydrometer is stable, proceed to the next step.

17. Transfer beer to secondary fermenter. Sanitize siphoning equipment and an airlock and carboy bung or stopper. Siphon the beer from the primary fermenter into the secondary.

### BEYOND BREWING DAY— SECONDARY FERMENTATION

18. Secondary fermentation. Allow the beer to condition in the secondary fermenter for 1 week before proceeding with the next step. Timing now is somewhat flexible.

### BOTTLING DAY—ABOUT 2 WEEKS AFTER BREWING DAY

19. Sanitize siphoning and bottling equipment.

20. Mix a priming solution (a measured amount of sugar dissolved in water to carbonate the bottled beer). Use the following amounts, depending on which type of sugar you will use:

- Corn sugar (dextrose)  $\frac{2}{3}$  cup in 16 oz water.
- Table sugar (sucrose)  $\frac{5}{8}$  cup in 16 oz water.

Then bring the solution to a boil and pour into the bottling bucket.

21. Siphon beer into bottling bucket and mix with priming solution. Stir gently to mix—don't splash.

22. Fill and cap bottles.

### 2–3 WEEKS AFTER BOTTLING DAY

23. Condition bottles at room temperature for 2-3 weeks. After this point, the bottles can be stored cool or cold.

24. Serving. Pour into a clean glass, being careful to leave the layer of sediment at the bottom of the bottle. Cheers!