

TALLGRASS BREWING OASIS (Pro Series)

Official NORTHERN BREWER Instructional Document

Oasis is a Double ESB/IPAish beer that came about from playing around with one of Tallgrass founder Jeff Gill's favorite homebrew recipes. At a hefty 7.2% ABV and 93 IBU, Oasis is a big beer with over-the-top hops and surprisingly sturdy malt backbone. Definitely not a fruit-extract seasonal shandy, this beer is meant to be enjoyed on the back porch, the front porch, or even on the stoop. What's a stoop? Well, it's a good place to drink beer, is what it is.

Brewer's Notes: For the 0" Cascade addition, a hop stand of 20 minutes can be conducted - after the hops are added and the heat turned off, let the wort rest for up to 20 minutes prior to chilling to extract maximum aroma & a little extra bitterness. Tallgrass head brewer Andrew Hood recommends chilling the wort to 67°F before pitching yeast.

O.G.: 1.072 READY: 6 WEEKS

1-2 weeks primary, 2-4 weeks secondary,
1-2 weeks bottle conditioning

KIT INVENTORY:

MAILLARD MALTS™ SPECIALTY GRAIN

- 1 lbs Briess Caramel 60L
- 1 lbs Briess Caramel 40L

MAILLARD MALTS™ EXTRACTS & OTHER FERMENTABLES

- 6.3 lbs Gold malt syrup
- 3.15 lb Gold malt syrup late addition (15 min)
- 5 oz Corn Sugar late addition (15 min)

HOPTIMUS REX™ PREMIUM HOPS & OTHER FLAVORINGS

- 1 oz German Northern Brewer (60 min)
- 1 oz Columbus (60 min)
- 1 oz Cascade (30 min)
- 0.5 oz Columbus (15 min)
- 0.25 oz German Northern Brewer (15 min)
- 1 oz Cascade (0 min)
- 0.5 oz Cascade (dry hop 7 days)
- 0.5 oz Columbus (dry hop 7 days)

YEAST

- Yeast 1098 British Ale. Apparent attenuation: 73-75%. Flocculation: medium. Optimum temp: 64°-72° F.

PRIMING SUGAR

- 5 oz Priming Sugar (save for Bottling Day)

BEFORE YOU BEGIN ...

MINIMUM REQUIREMENTS

- Homebrewing starter kit for brewing 5 gallon batches
- Boiling kettle of at least 3.5 gallons capacity

- A 5 gallon glass carboy, with bung and airlock, to use as a secondary fermenter - If you do not have a secondary fermenter you may skip the secondary fermentation and add an additional week to primary fermentation before bottling

- Approximately two cases of either 12 oz or 22 oz pry-off style beer bottles

UNPACK THE KIT

- Refrigerate the yeast upon arrival
- Locate the Kit Inventory (above) - this is the recipe for your beer, so keep it handy
- Doublecheck the box contents vs. the Kit Inventory
- Contact us immediately if you have any questions or concerns!

PROCEDURE

A FEW DAYS BEFORE BREWING DAY

1. Remove the liquid Wyeast pack from the refrigerator, and "smack" as shown on the back of the yeast package. Leave it in a warm place (70-80° F) to incubate until the pack begins to inflate. Allow at least 3 hours for inflation; some packs may take up to several days to show inflation. Do not brew with inactive yeast - we can replace the yeast, but not a batch that fails to ferment properly. If you are using dry yeast, no action is needed.

ON BREWING DAY

2. Collect and heat 2.5 gallons of water.

3. For mail-order customers grains for extract kits come crushed by default, but if you requested uncrushed grains, crush them now. Pour crushed grain into supplied mesh bag and tie the open end in a knot. Steep for 20 minutes or until water reaches 170°F. Remove bag and discard.

4. Bring to a boil and add the 6.3 lbs Gold malt syrup. Remove the kettle from the burner and stir in the Gold malt syrup.

5. Return wort to boil. The mixture is now called "wort", the brewer's term for unfermented beer.

- Add 1 oz German Northern Brewer and 1 oz Columbus hops and boil for 60 minutes.

- Add 1 oz Cascade hops 30 minutes before the end of the boil.

- Add 0.5 oz Columbus hops, 0.25 oz German Northern Brewer hops, 3.15 lbs Gold Malt Syrup and 5 oz Corn Sugar 15 minutes before the end of the boil.

- Add 1 oz Cascade hops at the end of the boil.

6. Cool the wort. When the 60-minute boil is finished, cool the wort to approximately 100° F as rapidly as possible. Use a wort chiller, or put the kettle in an ice bath in your sink. **NOTE:** You may also perform a hop stand - turn off the kettle and wait 20 minutes before chilling.

7. Sanitize fermenting equipment and yeast pack. While the wort cools, sanitize the fermenting equipment - fermenter, lid or stopper, fermentation lock, funnel, etc - along with the yeast pack and a pair of scissors.

8. Fill primary fermenter with 2 gallons of cold water, then pour in the cooled wort. Leave any thick sludge in the bottom of the kettle.

9. Add more cold water as needed to bring the volume to 5 gallons.

10. Aerate the wort. Seal the fermenter and rock back and forth to splash for a few minutes, or use an aeration system and diffusion stone.

11. **OPTIONAL:** if you have our Mad Brewer Upgrade or Gravity Testing kits, measure specific gravity of the wort with a hydrometer and record.

12. Add yeast once the temperature of the wort is 78°F or lower (not warm to the touch). Use the sanitized scissors to cut off a corner of the yeast pack, and carefully pour the yeast into the primary fermenter.

13. Seal the fermenter. Add approximately 1 tablespoon of water to the sanitized fermentation lock. Insert the lock into rubber stopper or lid, and seal the fermenter.

14. Move the fermenter to a warm, dark, quiet spot until fermentation begins.

BEYOND BREWING DAY, WEEKS 1-2

15. Active fermentation begins. Within approximately 48 hours of Brewing Day, active fermentation will begin - there will be a cap of foam on the surface of the beer, and you may see bubbles come through the fermentation lock. 16. Active fermentation ends. Approximately 1-2 weeks after brewing day, active fermentation will end: the cap of foam falls back into the new beer, bubbling in the fermentation lock slows down or stops.

16. Active fermentation ends. Approximately 1-2 weeks after brewing day, active fermentation will end: the cap of foam falls back into the new beer, bubbling in the fermentation lock slows down or stops.

17. Transfer beer to secondary fermenter. Sanitize siphoning equipment and an airlock and carboy bung or stopper. Siphon the beer from the primary fermenter into the secondary.

BEYOND BREWING DAY— SECONDARY FERMENTATION

18. Secondary fermentation. Allow the beer to condition in the secondary fermenter for 2-4 weeks before proceeding with the next step. Timing now is somewhat flexible.

19. Add the dry hops. Add 0.5 oz Cascade and 0.5 oz Columbus hops to the secondary fermenter 1 week before bottling day.

BOTTLING DAY—ABOUT 1 MONTH AFTER BREWING DAY

20. Sanitize siphoning and bottling equipment.

21. Mix a priming solution (a measured amount of sugar dissolved in water to carbonate the bottled beer) of $\frac{2}{3}$ cup priming sugar in 16 oz water. Bring the solution to a boil and pour into the bottling bucket.

22. Siphon beer into bottling bucket and mix with priming solution. Stir gently to mix, don't splash.

23. Fill and cap bottles.

1-2 WEEKS AFTER BOTTLING DAY

24. Condition bottles at room temperature for 1-2 weeks. After this point, the bottles can be stored cool or cold.

25. Serving. Pour into a clean glass, being careful to leave the layer of sediment at the bottom of the bottle. Cheers!