

WORLD WIDE LAGER

Official NORTHERN BREWER Instructional Document

The next time somebody asks for a Heineken, politely suggest a bottle of your own World Wide Lager instead. Engineered to satisfy fans of the Green Bottle as well as your own more exacting tastes, this kit exhibits the refined, dry maltiness and crisp hopping of a choice Northern European pilsner with none of the light-struck off-flavors or import prices. Straw-gold with a medium-light body, fresh malt flavor and spicy hop aromatics, and a dry finish.

O.G.: 1.049 READY: 2 MONTHS

2 weeks primary, 4 weeks secondary 2 weeks bottle conditioning

KIT INVENTORY:

MAILLARD MALTS™ EXTRACTS & OTHER FERMENTABLES

- 6 lbs Pilsen malt syrup
- 1 lbs Golden Light dry malt extract

BOIL ADDITIONS

- 1 oz German Perle (60 min)
- 0.5 oz Saaz (10 min)
- 0.5 oz Saaz (1 min)

YEAST

- **DRY YEAST (DEFAULT):** Saflager S-23. Optimum temperature: 60-72°F
- **LIQUID YEAST OPTION:** Wyeast #2042 Danish Lager Yeast. Optimum temperature: 46-56°F

PRIMING SUGAR

- 5 oz Priming Sugar (save for Bottling Day)

These simple instructions are basic brewing procedures for this Northern Brewer extract beer kit; please refer to your starter kit instructions for specific instructions on use of equipment and common procedures such as siphoning, sanitizing, bottling, etc.

For more detailed extract brewing instructions, please visit www.northernbrewer.com

BEFORE YOU BEGIN ...

MINIMUM REQUIREMENTS

- Homebrewing starter kit for brewing 5 gallon batches
- Boiling kettle of at least 3.5 gallons capacity
- A 5 gallon glass carboy, with bung and airlock, to use as a secondary fermenter
- Approximately two cases of either 12 oz or 22 oz pry-off style beer bottles

UNPACK THE KIT

- Refrigerate the yeast upon arrival
- Locate the Kit Inventory (above) - this is the recipe for your beer, so keep it handy
- Doublecheck the box contents vs. the Kit Inventory
- Contact us immediately if you have any questions or concerns!

PROCEDURE

A FEW DAYS BEFORE BREWING DAY

1. Remove the liquid Wyeast pack from the refrigerator, and "smack" as shown on the back of the yeast package. Leave it in a warm place (70-80° F) to incubate until the pack begins to inflate. Allow at least 3 hours for inflation; some packs may take up to several days to show inflation. Do not brew with inactive yeast - we can replace the yeast, but not a batch that fails to ferment properly. If you are using dry yeast, no action is needed.
2. Prepare a yeast starter. Follow the Yeast Starter Kit instructions. Allow the starter to incubate for at least one day.

ON BREWING DAY

3. Collect and heat 2.5 gallons of water.
4. Bring to a boil and add 6 lbs Pilsen malt syrup and 1 lbs Golden Light dry malt extract. Remove the kettle from the burner and stir in the Pilsen malt syrup and Golden Light DME.
5. Return wort to boil. The mixture is now called "wort", the brewer's term for unfermented beer.
 - Add 1 oz German Perle hops, and boil for 60 minutes.
 - Add 0.5 oz Saaz hops 10 minutes before the end of the boil.
 - Add 0.5 oz Saaz hops 1 minute before the end of the boil.
6. Cool the wort. When the 60-minute boil is finished, cool the wort as close to 56° F as rapidly as possible. Use a wort chiller, or put the kettle in an ice bath in your sink.
7. Sanitize fermenting equipment and yeast pack. While the wort cools, sanitize the fermenting equipment - fermenter, lid or stopper, fermentation lock, funnel, etc - along with the yeast pack and a pair of scissors.
8. Fill primary fermenter with 2 gallons of cold water, then pour in the cooled wort. Leave any thick sludge in the bottom of the kettle.
9. Add more cold water as needed to bring the volume to 5 gallons.
10. Aerate the wort. Seal the fermenter and rock back and forth to splash for a few minutes, or use an aeration system and diffusion stone.

11. **OPTIONAL:** if you have our Mad Brewer Upgrade or Gravity Testing kits, measure specific gravity of the wort with a hydrometer and record.

12. Add yeast once the temperature of the wort is as close to 56°F as possible. Use the sanitized scissors to cut off a corner of the yeast pack, and carefully pour the yeast into the primary fermenter.

13. Seal the fermenter. Add approximately 1 tablespoon of water to the sanitized fermentation lock. Insert the lock into rubber stopper or lid, and seal the fermenter.

14. Move the fermenter to a dark, quiet spot until fermentation begins.

BEYOND BREWING DAY, WEEKS 1-2

15. Active fermentation begins. Within approximately 48 hours of Brewing Day, active fermentation will begin - there will be a cap of foam on the surface of the beer, and you may see bubbles come through the fermentation lock.

16. Active fermentation ends. Approximately 1-2 weeks after brewing day, active fermentation will end: the cap of foam falls back into the new beer, bubbling in the fermentation lock slows down or stops.

17. Transfer beer to secondary fermenter. Sanitize siphoning equipment and an airlock and carboy bung or stopper. Siphon the beer from the primary fermenter into the secondary.

BEYOND BREWING DAY— SECONDARY FERMENTATION

18. Lagering. Slowly lower the temperature of the beer to as close to 35-40° F as your equipment allows. The best method is to lower the temperature by a couple of degrees each day until the target temperature is reached. Allow the beer to condition in the secondary fermenter for 4 weeks before proceeding with the next step. Timing now is somewhat flexible.

BOTTLING DAY—ABOUT 6 WEEKS AFTER BREWING DAY

19. Sanitize siphoning and bottling equipment.

20. Mix a priming solution (a measured amount of sugar dissolved in water to carbonate the bottled beer) of $\frac{2}{3}$ cup priming sugar in 16 oz water. Bring the solution to a boil and pour into the bottling bucket.

21. Siphon beer into bottling bucket and mix with priming solution. Stir gently to mix—don't splash.

22. Fill and cap bottles.

2 WEEKS AFTER BOTTLING DAY

23. Condition bottles at room temperature for 2 weeks. After this point, the bottles can be stored cool or cold.

24. Serving. Pour into a clean glass, being careful to leave the layer of sediment at the bottom of the bottle. Cheers!